

August 16, 2017

Maintenance bulletin on supplementary external ground lug mounting screw – FMV LED

**Generation II FMV LED floodlights (3L – 15L) purchased from August 1, 2015 and
Generation II FMVA LED floodlights (20L – 25L) purchased from November 1, 2016**

Dear Customer,

Our FMV LED floodlight series includes a supplementary external ground (in addition to the primary internal ground). If you are utilizing the external ground, please ensure you follow the directions in our installation and maintenance sheet to ensure the external ground lug mounting screw is torqued before connecting the ground wire.

Per our instruction sheet, the external ground lug mounting screw must be torqued to 19 inch pounds.

The instruction sheets are available on our website.

Please see the links below.

FMV 3L – 15L:

<http://www.cooperindustries.com/content/dam/public/crousehinds/resources/pdfs/instruction-sheets/if1737.pdf>

FMVA 20L and FMVA 25L:

<http://www.cooperindustries.com/content/dam/public/crousehinds/resources/pdfs/instruction-sheets/if1828.pdf>

Thank you for your business and if you have any questions please feel free to contact me or your Crouse-Hinds representative.

Sincerely,

Andrew Agan